

# PREVENT STORM WATER CONTAMINATION

## *Best Management Practices for*

# Electrical, Photographic & Optical Manufacturers

### Outdoor unloading and loading

- ✦ Confine loading/unloading activities to a designated area.
- ✦ Consider performing loading/unloading activities indoors or in a covered area.
- ✦ Consider covering loading/unloading area with permanent cover (e.g. roof) or temporary cover (e.g. tarps).
- ✦ Close storm drains during loading/unloading activities in surrounding areas.
- ✦ Avoid loading/unloading materials in the rain.
- ✦ Inspect the unloading/loading areas to detect problems before they occur.
- ✦ Inspect all containers prior to loading/unloading of any raw or spent materials.
- ✦ Consider berming, curbing or diking loading/unloading areas.
- ✦ Dead-end sump where spilled materials could be directed.
- ✦ Drip pans under hoses.
- ✦ Use dry clean-up methods instead of washing the areas down.
- ✦ Train employees on proper loading/unloading techniques and spill prevention and response.

### Outdoor material storage (including waste and particulate emission management)

- ✦ Confine storage of materials, parts and equipment to designated areas.
- ✦ Consider secondary containment using curbing, berming or diking all liquid storage areas.
- ✦ Train employees in spill prevention and response techniques.
- ✦ Train employees on proper waste control and disposal.
- ✦ Consider covering tanks.
- ✦ Ensure that all containers are closed (e.g. valves shut, lids sealed, caps closed).
- ✦ Wash and rinse containers indoors before storing them outdoors.

- ✦ If outside or in covered areas, minimize run-on of storm water by grading the land to divert flow away from containers.
- ✦ Leak detection and container integrity testing.
- ✦ Direct runoff to on-site retention pond.
- ✦ Inventory all raw and spent materials.
- ✦ Clean around vents and stacks.
- ✦ Place tubs around vents and stacks to collect particulate.
- ✦ Inspect air emission control systems (e.g. baghouses) regularly, and repair or replace when necessary.
- ✦ Store wastes in covered, leak proof containers (e.g. dumpsters, drums).
- ✦ Consider shipping all wastes to offsite landfills or treatment facilities.
- ✦ Ensure that hazardous waste disposal practices are performed in accordance with Federal, State and local requirements.

### If spills occur:

- ✦ ***Stop the source of the spill immediately.***
- ✦ ***Contain the liquid until cleanup is complete.***
- ✦ ***Deploy oil containment booms if the spill may reach the water.***
- ✦ ***Cover the spill with absorbent material.***
- ✦ ***Keep the area well ventilated.***
- ✦ ***Dispose of clean-up materials properly.***
- ✦ ***Do not use emulsifier or dispersant.***



**City of Phoenix**

STREET TRANSPORTATION DEPARTMENT  
STORM WATER MANAGEMENT SECTION

(602) 256-3190

Upon request, the Street Transportation Department will make this publication available through appropriate auxiliary aids or services to accommodate an individual with a disability by calling 256-3190; or faxing a request to 495-2016.